

June 15th, 2015

Subject: Star Industries Work Platform on Genie branded telehandlers.

Subject to the terms and conditions of this letter, Genie Industries Inc. authorizes the owners of a Genie branded 636, 644, 844, 1056, 1256, or 1544 telehandler to use the Star Industries Work Platform, Models 1204G, 1206G, 1208G, and 1210G, based on the requirements hereinafter. The Genie GTH- 5519 is only authorized to use Star Industries Work Platform Models 1204G and 1206G, based on the requirements hereinafter. This letter supersedes all previous versions.



Warning:

Failure to comply with all restrictions, instructions and warnings contained in this letter, in all Operators' Manuals and Safety Manual could result in death or serious injury.

Approved Serial range

The following models are approved based on the serial range as follows:

- GTH5519 – From GTH5514B-101
- GTH636 – From GTH0614H-10000
- GTH644/844 – From GTH0813-16606
- GTH1056 – From GTH1012-16292
- GTH1256 – From GTH1215M-101
- GTH1544 – From GTH1514B-22830

Owner/Employer/Operator Requirements

- 1) The owner, employer and the operator shall comply with all applicable jobsite, local, state, country, employer, manufacturer rules, regulations, and standards (e.g. ANSI/ITSDF B56.6) related to the use of the equipment with the work platform attachment.
- 2) A copy of this letter, and the Star Industries Work Platform Safety Manual, must accompany the telehandler operator and safety manuals at all times in the weather resistant storage compartment located on the equipment. Read, understand and follow the proper installation and operating instructions of the attachment.
- 3) Operators must be trained and qualified on how to safely operate the equipment and be familiar with the specific model of Genie equipment, and attachment, as follows:
 - a) Be familiar, and comply, with all equipment operating and safety manuals.
 - b) Understand all control functions, decals and warnings.
 - c) Be aware of and understand all safety devices specific to the equipment being used.
 - d) Be instructed regarding the specific hazards associated with using the Genie telehandler with the attachment and utilize all means, including those provided by the user or employer, to avoid them.
- 4) Prior to use, both the telehandler and the work platform must be in proper working condition and configuration.
- 5) The combined weight of the work platform, occupants, tools and materials shall not exceed one-third the maximum allowable load capacity, at the related load center position (e.g. 24 inches), within any



load zone on the applicable load chart. Example: If the standard load capacity, within a particular zone, allows 8,000 lbs. of capacity, the new maximum load capacity is $8,000/3 = 2,667$ lbs.

Specific Training

- 1) The employer shall provide any additional training to the operator, and other personnel, that's deemed necessary to safely operate the Genie telehandler with the attachment.
- 2) A competent person shall supervise the operation and make a determination regarding load position, boom location, ground support, travel route, overhead obstructions, and speed of movement necessary to ensure safety.

Use Requirements/Considerations

- 1) This approval only applies for the primary intended purpose and use of the Genie telehandler, as defined by ANSI/ITSDF B56.6 and CSA B335.
- 2) Star Industries is responsible for the attachment:
 - a) Design
 - b) Fabrication
 - c) Workmanship
 - d) Structural integrity
 - e) Fit and function
 - f) Overall quality
 - g) Any operating and safety instructions specific to the attachment
 - h) Clearly marking the attachment in accordance with ANSI/ITSDF B56.6

In consideration for Genie's authorization herein, the equipment owner hereby agrees to indemnify and hold harmless Genie Industries Inc. and its parent and affiliated companies against any and all liability, claims, suits, losses, costs and legal fees caused by, arising out of, or resulting from the approved modification/application of the Genie equipment; any negligent act in the operation of the equipment by the owner, user and/or operator; the failure to comply with the criteria set forth in this letter related to the modification/application; the design, manufacture and installation of any modification; the safety rules and operating instructions in the Operator's Manual; the design and placement of any safety decals; the operation of the equipment by the owner, user and/or operator; and any negligent act or omission related to the equipment, its use or its modification.

BY PROCEEDING WITH THE MODIFICATION/APPLICATION AUTHORIZED HEREIN, YOU AGREE TO THE CONTENTS OF THIS LETTER AND ITS CONDITIONS. IF YOU DO NOT AGREE, DO NOT PROCEED WITH THE PROPOSED MODIFICATION/APPLICATION.