TECH_TIP

Service Call: Front and/or rear side marker lights have become detached from their covers.

Tools Needed:

Snap ring pliers
Wire cutters
8 mm deep well socket
8 mm wrench
3/8" Ratchet with long extension

Model:

RL4 With Vertical Mast from SN RL415-101 to RL416J-1082



TECH_TIP

Tech Tips Safety Rules



Danger

Failure to obey the instructions and safety rules in the appropriate Operator's Manual and Service Manual for your machine will result in death or serious injury. Many of the hazards identified in the operator's manual are also safety hazards when maintenance and repair procedures are performed.

Do Not Perform Maintenance Unless:

- > You are trained and qualified to perform maintenance on this machine.
- You read, understand and obey:
 - manufacturer's instructions and safety rules
 - employer's safety rules and worksite regulations
 - o applicable governmental regulations
- You have the appropriate tools, lifting equipment and a suitable workshop.

The information contained in this tech tip is a supplement to the service manual. Consult the appropriate service manual of your machine for safety rules and hazards.

TECH_TIP

There is as possibility of the covers becoming detached from the marker lights over time. If this happens, there is a kit which should be installed which will fix the issue and prevent it from happening again.

Order kit 1270634 - Marker light kit.



The kit comes with the instructions, light assemblies, washers, cable ties, and the snap rings that will secure the covers to the light assemblies.

