

TECH TIPS

Service Call:

**Problem with Touch Pad Controls at
Platform or Ground**

Tools Needed:

None

Model:

Z-135, Z-8060, S-125



Tech Tips Safety Rules



Danger

Failure to obey the instructions and safety rules in the appropriate Operator's Manual and Service Manual for your machine will result in death or serious injury. Many of the hazards identified in the operator's manual are also safety hazards when maintenance and repair procedures are performed.

Do Not Perform Maintenance Unless:

- You are trained and qualified to perform maintenance on this machine.
- You read, understand and obey:
 - manufacturer's instructions and safety rules
 - employer's safety rules and worksite regulations
 - applicable governmental regulations
- You have the appropriate tools, lifting equipment and a suitable workshop.

The information contained in this tech tip is a supplement to the service manual. Consult the appropriate service manual of your machine for safety rules and hazards.

Step 1

Pull out E-stop and turn to Ground Control (or Platform to check Platform Touch Pad).

When you push any function on the touch pad the alarm should sound. If the alarm does not sound when touching a function the touch pad is bad and requires replacement.



Step 2