Maintenance Inspection Corrugated Hose Turbo To Air Cleaner

Tools Needed: Flashlight

Model:

GTH5519 GTH5514B-101 to current



Tech Tips Safety Rules



Danger

Failure to obey the instructions and safety rules in the appropriate Operator's Manual and Service Manual for your machine will result in death or serious injury. Many of the hazards identified in the operator's manual are also safety hazards when maintenance and repair procedures are performed.

Do Not Perform Maintenance Unless:


- You are trained and qualified to perform maintenance on this machine.
- You read, understand and obey:
 - manufacturer's instructions and safety rules
 - employer's safety rules and worksite regulations
 - applicable governmental regulations
- You have the appropriate tools, lifting equipment and a suitable workshop.

The information contained in this tech tip is a supplement to the service manual. Consult the appropriate service manual of your machine for safety rules and hazards.

Step 1


The hose on the engine can be subject to cyclic thermal break down and deteriorate over time.

Perform this inspection daily or every eight hours.



Step 2

The hose should be inspected by looking over the back side of the engine with a flashlight. This procedure should be performed with a cool engine.



Step 3

Inspect the hose for any damage or holes. Picture to the right depicts a damaged hose.



Step 4

If there is any damage or holes in the hose, the machine must be taken out of service until the hose can be replaced. Order Genie part number 55.0208.0114GT Install and returned the machine to service.